

These instructions are generic and suitable for ALL display cases. Each display case is pre built and disassembled prior to sending out for delivery so the quantity and type of fixings can vary.

Please also watch the online videos for assembly guidance

35mm Black Pan Head Screws for main assembly
25mm Stainless Steel Dowels for top panel to hang face
32mm Wall Hanging Brackets for hanging the case (rear is pre drilled)
25mm Countersunk Screws to fit brackets to rear
20mm Panel Pins to help hold magnetic tape to front edge
12mm Self Adhesive Magnetic Edging Strip to create dust seal
Internal Cover Plates (left and Right)
12mm Thick Black Side Panels (these will have logos to the outside edges)
12mm Thick Black Top & Bottom Panels (holes for steel dowels to go on outside edge)
Slotted Back Panel (remove protective film once assembled and before slotting in figure stands)
Clear Figure Stands approximately 100 to slot into back panel
5m Long Self Adhesive LED Lighting Kit with Clips (to stick to inside edge)
400mm Face Panel Hanging Bracket
M4 Black Socket Head Bolt and Nut to fix logo and bracket
Face Panel pre drilled holes for bracket and logo
4x40 Screw and Wall Plug (Plasterboard or Solid Wall)
Free Logo

YOU MUST CHECK ALL PACKAGING & CONTENTS FOR DAMAGE WITHIN 48 HOURS OF RECEIPT AND BEFORE ASSEMBLY AND NOTIFY ME OF ANY BREAKAGES. DAMAGED CONTENTS CANNOT BE REPLACED AFTER THIS TIME

You will need:

1. Cordless Drill/Driver or Manual Screwdriver
2. Hammer
3. Scissors



For further help please observe the instructions page of the website where there are many helpful videos. www.collectordisplaysuk.com

Please watch the online videos and read instructions fully before you attempt to assemble the case.

1. First the 2 x 25mm steel dowels can be placed into the 2 holes on the top panel (use a hammer on a flat surface). Screw top panel to back panel using 32mm panhead screws, be careful not to overtighten. The top panel edges should line up with the back panel edges. Make sure that the 25mm steel dowels are facing up as in the images.
2. Repeat the process with the bottom panel. No steel dowels are required on this panel so the holes can go on the underside.
3. Line up the left panel with the panel edges and screw into place using the 32mm panhead screws (these may also have holes for steel dowels but they go on the inside and will be covered by the graphic)
4. Repeat the process with the right panel then screw the left and right panels into the top and bottom panels
5. Now peel the backing from the internal death star side walls and stick to the panel inside with the logo at the bottom.
6. Now apply the magnetic tape to the front edges of the side panels (see photographs) apply plenty of even pressure and then pin approximately every 200mm with the small panel pins. There are 2 short strips and 2 long strips, **DO NOT PIN CLOSE TO THE PANEL EDGE AS IT MAY SPLIT**
7. Unwind the LEDs from the roll.
Now decide where you want the cable to exit the cabinet, you can choose any corner.
8. Peel back the first 25mm or so from the connection end of the LED tape backing. Stick the first part of the LED tape so that it sits back from the front edge by approx 1mm now peel and stick the rest of the tape until you arrive back at the start. Cut the tape at the closest connection as indicated in the LED instructions. Be sure to go over the tape with even pressure after to make sure it is stuck. **If required** you can now apply some extra fixings supplied with the lights.
9. Carefully peel the protective film from the face panel. The steel tape has already been applied to the panel (this will contact the magnetic edging). Put the small M4 bolts through the logo and into the pre drilled holes on the face panel with the Bolt Head on the face side as in image. Put the nuts onto the rear of the angle bracket and tighten (Do not overtighten).
10. Peel off the protective film from the back panel then install Figure stands before fitting to wall by pushing in while rolling from left to right. **(THERE IS ALSO A VIDEO SHOWING HOW TO DO THIS)**
11. Screw wall brackets to rear of case with 25mm countersunk screws using holes provided (do not overtighten). Mark the wall and fit using the optional wall plugs provided. **(FITTING TIPS INCLUDED)**

12. PUT YOUR COLLECTIBLES IN AND ENJOY!





